

PHILIPS REMOTE PROGRAMMING:

1. PRESS AND HOLD SETUP KEY UNTIL RED LIGHT COMES ON
2. PRESS TV
3. PRESS 0117
4. RED LIGHT SHOULD GO OFF
5. PRESS AND HOLD SETUP KEY UNTIL RED LIGHT COMES ON
6. PRESS DVD/VCR
7. PRESS 1542
8. RED LIGHT SHOULD GO OFF